

Analysis Techniques for Quasi-Steady Data



Section 6: Analysis Techniques for Quasi-Steady Data

Kevin M. McPherson
PIMS Data Analyst
NASA Glenn Research Center




Quasi-Steady Topics for Discussion

- **OARE description**
- **Description of trimmean filter (TMF)**
- **Bias calibration**
- **Data storage**
- **Analysis and display of quasi-steady data**

Orbital Acceleration Research Experiment

- **Three axis Miniature Electrostatic Accelerometer (MESA) with an electrostatically suspended proof mass**
- **Full in-flight calibration station for bias and scale factor adjustments**
- **On-board microprocessor for in-flight experiment control, processing, and storage of data**
- **OARE coordinate system vs. Orbiter body coordinate system**

$$\begin{bmatrix} X_b \\ Y_b \\ Z_b \end{bmatrix} = \begin{bmatrix} X_{OARE} \\ Z_{OARE} \\ -Y_{OARE} \end{bmatrix}$$



Orbital Acceleration Research Experiment

- **OARE data is recorded in an inertial frame of reference**
 - an acceleration of the Orbiter in the positive x_b -axis direction is reported as a positive x_b -axis acceleration even though a free particle may appear to move in the negative x_b -axis relative to the accelerating Orbiter
- **Designed to measure low-frequency (< 1 Hz), low-level acceleration (nano-g sensitivity)**
 - frequency ranges are x-axis 0-1 Hz, y and z axis 0-0.1 Hz

Orbital Acceleration Research Experiment

- Typical (STS-78) OARE sensor ranges and resolution

	X-AXIS	Y,Z-AXIS
RANGE	RESOLUTION (nano-G)	RESOLUTION (nano-G)
A	305.2	762.9
B	30.52	60.12
C	3.052	4.578
RANGE	FULL SCALE RANGE (micro-g)	FULL SCALE RANGE (micro-g)
A	10,000	25,000
B	1,000	1,970
C	100	150



Trimmean Filter (TMF) Description

- **Necessary to mitigate the effects of higher amplitude, higher frequency accelerations**
 - removes infrequent, large amplitude, outlier data
- **TMF utilizes a sliding window to operate on a segment of data of pre-defined length**
- **The sliding window operates such that a segment of the Nth window of data is included in the (N+1)th window, resulting in some portion of data being considered in two consecutive TMF operations (see Figure 6-1)**
- **Most PIMS implementations of the TMF operate on 500 sample window every 25 seconds or on 3000 sample window every 8 seconds**

Trimmean Filter (TMF) Description

- **Consider a window of data of length t seconds (Figure 6-1)**
 - **Step 1 - Divide the data into overlapping segments**
 - **Step 2 - Sort the acceleration data in order of increasing magnitude**
 - **Step 3 - Calculate the parameter Q according to the equation below**

$$Q = \frac{[U(20\%) - L(20\%)]}{[U(50\%) - L(50\%)]}$$


- where U(x%) is the average of the upper x% of the ordered sample and L(x%) is the average of the lower x% of the ordered sample
- Q is a measure of the departure of the distribution contained in the sample from a normal distribution

Trimmean Filter (TMF) Description

- **Step 4A - Trim off each tail of the ordered distribution according to the value of the trimmean parameter alpha**


$$\alpha(Q) = \begin{cases} 0.05 & Q \leq 1.75 \\ 0.05 + 0.35 * \frac{(Q - 1.75)}{0.25} & 1.75 < Q < 2.0 \\ 0.4 & Q \geq 2.0 \end{cases}$$

- **Step 4B - Calculate the mean of the remaining trimmed distribution**
- **TMF parameters example (Figure 6-2)**




Trimmean Filter (TMF) Description

- **For a pure Gaussian distribution of data, 5 percent of the data is trimmed from each tail of the original sorted distribution**
- **For a given segment of time, a maximum of 40 percent of the data is trimmed off each tail**
- **Typical values for Q and alpha result in 30-50 percent of the original data being discarded for a nominal shuttle mission**



OARE/MAMS Bias Operations

- **OARE bias is caused primarily by dielectric charging of the ceramic insulator material that surrounds the cylindrical axis electrodes**
- **Bias calibrations are nominally performed throughout each mission at regularly programmed intervals**
 - **in-flight correction for bias**
 - **performed for the following additional conditions**
 - sensor instrument temperature change of 5 degrees Celsius since the completion of the last calibration sequence
 - sensor “down ranges” to range not calibrated in the previous calibration sequence
 - ground command initiation



OARE Bias Operations

- **Bias calibration sequence of steps**
 - **50 seconds of data collected**
 - **trimmean filter (TMF) applied to the resulting 500 data points**
 - **sensor is rotated 180 degrees and another 50 seconds of data are collected**
 - **TMF applied to the second 500 data points**
 - **the outputs of the two TMF operations are summed and divided by two**
 - **resulting value represents the bias value**

Analysis and Display of Quasi-Steady Data

Display Format	Regime(s)	Notes
Acceleration versus Time	Transient, Quasi-Steady, Vibratory	<ul style="list-style-type: none"> precise accounting of measured data with respect to time; best temporal resolution
Interval Min/Max Acceleration versus Time	Vibratory, Quasi-Steady	<ul style="list-style-type: none"> displays upper and lower bounds of peak-to-peak excursions of measured data good display approximation for time histories on output devices with resolution insufficient to display all data in time frame of interest
Interval Average Acceleration versus Time	Vibratory, Quasi-Steady	<ul style="list-style-type: none"> provides a measure of net acceleration of duration greater than or equal to interval parameter
Trimmed Mean Filtered Acceleration versus Time	Quasi-Steady	<ul style="list-style-type: none"> removes infrequent, large amplitude outlier data
Quasi-Steady Mapped Acceleration versus Time	Quasi-Steady	<ul style="list-style-type: none"> use rigid body assumption and vehicle rates and angles to compute acceleration at any point in the vehicle
Quasi-Steady Three-Dimensional Histogram (QTH)	Quasi-Steady	<ul style="list-style-type: none"> summarize acceleration magnitude and direction for a long period of time indication of acceleration "center-of-time" via projections onto three orthogonal planes

Analysis and Display of Quasi-Steady Data

- **No frequency domain analysis performed on quasi-steady acceleration data**
- **Data recorded at a rate of 10 samples per second**
- **Time domain plot types available**
 - **Raw acceleration data**
 - g vs. t plot of 10 sample per second data
 - **TMF acceleration data**
 - g vs. t plot, t is a function of the TMF interval selected
 - for Canopus Systems, Inc. provided data, TMF interval is 1 data point every 25 seconds
 - **Interval average acceleration data**

$$x_{avgk} = \frac{1}{M} \sum_{i=1}^M x_{[(k-1)*M+i]} \quad k = 1, 2, \dots, \left\lfloor \frac{N}{M} \right\rfloor$$

- M=number of points in the time series interval selected, typically 1 second intervals
- N=total number of points in the time series being considered



Analysis and Display of Quasi-Steady Data

- **Time domain plot types available**
 - **Quasi-Steady Three-dimensional histograms (QTH)**
 - displays a summary of acceleration vector magnitude and alignment projected on three orthogonal planes
 - time series analysis using a 2-dimensional histogram for each combination of the three axes: XY, XZ, YZ
 - accumulates the number of times the acceleration vector magnitude falls within user-defined 2-dimensional bins
 - count is divided by the total number of points considered to normalize the results
 - gives a percentage of time representation of the magnitude and orientation of the quasi-steady acceleration vector
 - makes comparisons of quasi-steady data from [QTH plots] STS mission to STS mission or ISS increment to ISS increment more meaningful


Analysis and Display of Quasi-Steady Data

- **Additional options for all time domain plots**
 - **Map quasi-steady acceleration data to the Orbiter CG or to an experiment location**
 - requires use of the vehicle (Orbiter or ISS) body rates and body angles
 - mapping is accomplished via the following calculations
 - determine the acceleration at the CG via

$$a_{CG} = a_{ML} - a_{ggML} - a_{EulerML}$$


- where ML = measurement location
- determine the acceleration at the new location via

$$a_{new} = a_{CG} + a_{ggnew} + a_{Eulernew}$$




Analysis and Display of Quasi-Steady Data

- **Additional options for all time domain plots**
 - **Select frame of reference as either inertial or science community**
 - **Select the coordinate system based on vehicle**
 - For Orbiter, use either Orbiter body, Orbiter structural, or specialized coordinate system (i.e., CGF coordinates on USML-2)
 - For ISS, many coordinates systems are available




Post-Mission Quasi-Steady Data Storage

- **OARE data stored on NASA GRC file server**
beech.lerc.nasa.gov
- **Each OARE supported STS mission since USML-2 has the following subdirectories under pub/OARE/<mission>**
 - **canopus**
 - stored in ASCII format
 - contains OARE TMF data provided by Canopus Systems, Inc. after the mission
 - data stored in body coordinate system, inertial frame of reference
 - **MAWS data**
 - stored in ASCII format
 - MAWS = Microgravity Analysis Workstation
 - contains analytical prediction data for the quasi-steady environment
 - data available for STS-73, STS-75, and STS-78
 - data stored in body coordinate system, science community frame of reference (opposite of inertial frame of reference described earlier)




Quasi-Steady Data Storage

- **Each OARE supported STS mission since USML-2 has the following subdirectories under pub/OARE/<mission>**
 - **msfc-processed**
 - stored in binary format
 - contains 10 sample per second data where the acceleration data are represented in acceleration units
 - stored in OARE sensor coordinates, inertial frame of reference
 - **msfc-raw**
 - stored in binary format
 - contains completely unprocessed raw data where the acceleration data are represented in raw counts form
 - stored in OARE sensor coordinates, inertial frame of reference



Analysis and Display of Quasi-Steady Data


- **Raw OARE acceleration data**
 - **Figure 6-3 LMS Water Dump and Attitude Change**
 - **Figure 6-5 USML-2 Solar Inertial Attitude**
 - **Figure 6-7 USMP-3 Vernier Thruster Firings**
- **TMF OARE acceleration data**
 - **Figure 6-4 LMS Water Dump and Attitude Change**
 - **Figure 6-6 USML-2 Solar Inertial Attitude**
 - **Figure 6-8 USMP-3 Vernier Thruster Firings**
 - **Figure 6-9 USML-2 Supply Water Dump**




Analysis and Display of Quasi-Steady Data


- **QTH plots**
 - **Figure 6-10 LMS Mission Plot**
 - **Figure 6-11 USML-2 Solar Inertial Attitude**
 - **Figure 6-12 USMP-2 Mission Plot**
 - **Figure 6-13 LMS Crew Active Period**
 - **Figure 6-14 LMS Crew Sleep Period**


TMF Process







MEIT 1999 Figure 6-2: OARE TMF Data Showing TMF Parameter Comparison from STS-73 (USML-2)







MEIT 1999 Figure 6-4: OARE TMF Data During Water Dump and Attitude Change from STS-78 (LMS)














MEIT 1999 Figure 6-8: OARE TMF Data Showing Vernier Thruster Firings from STS-75 (USMP-3)




MEIT 1999 Figure 6-9: OARE TMF Data Showing Water Dump from STS-73 (USML-2)






USML-2 Solar Inertial Attitude Data
Quasi-Steady Three Dimensional Histogram $X_{ct} = -0.037792 \mu\text{g}$ $Y_{ct} = -0.039693 \mu\text{g}$ $Z_{ct} = 0.21086 \mu\text{g}$

MET Start at 000/00:12:16.920
USMP-2 (STS-62) Mission Plot



MET Start at 008/17:00:16.920
LMS Mission – Crew Active Periods



0.35
0.3
0.25
0.2
0.15
0.1
0.05
0

Body Coordinates

Frame of Reference: Orbiter

T = 46.0 hours

MET Start at 009/09:00:07.920
LMS Mission – Sleep Cycles

