

ADVANCED METALLIC SEAL FOR HIGH TEMPERATURE APPLICATIONS

Jeff Layer
EG&G Pressure Science
Beltsville, Maryland

The U-Plex® seal is a static seal. It consists of two plies of material nested together during the forming process, that act independently when the seal is compressed, like a multi-leaf spring, yet act as one in containing pressure. Please note that most of the testing that has been done, and most of actual applications in service are small (less than 8 inches) diameter seals. However, we are in fact testing and refining the manufacturing process for the larger diameter seals and the benefits that apply to the small seals are applicable to U-Plex® Seals of any size.

What the U-Plex® seal does is improve the integrity and robustness of rigid ducting joints. What you get is increased elastic deflection. To illustrate this, I have a scale side-by-side comparison of the U-Plex® seal and the now conventional E-Seal®. The U-Plex® Seal is a static, reusable seal, and it is designed to operate in the elastic range of material. The object is to hold the seal as high as possible in the free state, yet not permanently deform the seal when it is compressed it in the cavity. A scale comparison of a standard section E-Seal® and a standard section U-Plex® Seal and the corresponding industry standard cavity dimension shows that when you compress the E-Seal®, you compress it .013 inches on each side. When the U-Plex® Seal is compressed, there is an additional amount of compression (.007 inches) per side. This extra .014 inches of compression is additional stored springback capability for the seal, so that if the cavity deforms during operation, the U-Plex® Seal has the ability to conform to the new cavity dimension and maintain contact with the sealing face. This is partially due to the multi-ply technology, but is also due to the geometry of the cross-section. A stress plot of a standard E-Seal® in its maximum (.027 inches) compression position shows that at the maximum stress level, which in this case actually slightly does exceed the yield stress of the material, has saturated about 50% of the cross-section. A similar stress plot of a U-Plex® Seal (maximum compression of .040 inches) shows that the plies do, in fact, act independently in distributing the stress, and that only about 10% of the section is saturated with a stress level that approaches the yield stress of the material. The actual amount of compression is an additional 50% over what you would get with the standard E-Seal®. The benefit of all this is that the U-Plex® Seal is much more compliant, and stores additional springback capability, so if the flanges or the sealing face is warped, or out-of-flat for any reason, the U-Plex® can conform and maintain a good quality seal. For the rigid joint applications, the U-Plex® Seal is capable of handling two-and-a-half to five times the amount of flange warpage or out of flatness, that a normal E-Seal® can handle. This translates into less rework of your ducting joints. The seal is also very locally compliant. The sealing face flatness can deviate up to .018 inches per inch of circumference. This far exceeds the capability of a standard E-Seal®. What is the benefit of this feature? The same as for deflection capability. If your sealing face is out of flat or

distorts due to welding, the U-Plex® Seal has exceptional ability to conform and provide a good quality seal.

Both E-Seals® and U-Plex® Seals are pressure-energized seals. The graph of leakage in SCFM per inch of duct diameter as a function of seal face separation shows how the U-Plex® Seal has improved pressure energization characteristics. This data shows that a nominal free height E-Seal® (which is .108 inches tall), will seal well below the .01 SCFM per inch of tube diameter industry standard, until the distance between the sealing two faces exceed the unrestrained free height of the seal. In contrast, a nominal free height U-Plex® Seal (which is .121 inches tall), is capable of controlling leakage even when the distance between the two sealing faces exceeds the unrestrained free height of the seal. This is possible due to the increased flexibility of the multi-ply U-Plex® Seal design and its exceptional ability to energize open and conform to an irregular surface under pressure. Because these two seals are designed to operate in the same cavity, you actually gain an additional .020 inches of possible cavity width variation before leakage becomes a problem.

Extensive testing has been done on this seal. The most rigorous test that has been done is an accelerated life test (SAE AS1895 Endurance Test) where the pressure is cycled and a large bending moment is cyclically applied to the pneumatic joint. This test was run at 1200°F for 200,000 cycles, and the leakage rate was measured and plotted every 20,000 cycles. The actual leakage at all of the different 20,000 cycle intervals never exceeded 10% of the .01 SCFM / inch of diameter allowable leakage. After 200,000 cycles, the measured leakage was 4% of the allowable leakage.

The standard U-Plex® Seal cross section is an internally pressurized two-ply, single convolution design. However, the number of material plies and the material thickness may be varied, convolutions may be added, and an externally pressurized version is also possible. There are a lot of options for this design.

Finally, all of the benefits that exist in the pneumatic joint application are applicable for use in a turbine engine. The same physical principles are at work, only on a larger scale. The increased elastic deflection feature is useful for segmented cavity surfaces. If the segmented cavity isn't flat, if it has bumps in it, the U-Plex® Seal is better able to conform and provide a tight seal. The design minimizes the likelihood of stress relaxation at high temperature. And the testing has shown a greater resistance to high cycle fatigue.

QUESTIONS

Q. What's the material?

A. Well, we can make that a variety of materials. The standard seal is made out of Inconel 718.

Q. Is the manufacturing of that seal mature now?

A. The small diameter seal is a very mature process, yes.

Q. Small being?

A. Up to about 7 or 8 inches in diameter.

Q. Have you ever made an 18 inch or larger?

A. We have made up to about three feet. For the three foot diameter seals, the process however, is being developed and testing for the large seals in process.

Q. Can you make a really large diameter seal?

A. It's never been done but the process is being developed.

Q. Do you expect wear vibrations between the two parts of the seal.

A. Well, part of the ASC 95 test is in fact a very rigorous vibration test that we have in fact done successfully with no visible or performance changes that we know.



EG&G PRESSURE SCIENCE

METALLIC

U-PLEX SEALS


INTRODUCTION

EG&G PRESSURE SCIENCE

- *Introduction to the U-Plex Seal*
- *Rigid Joint Features and Benefits*
- *Test Data*
- *Stress Plots*
- *Turbine Engine Benefits*

U-PLEX CROSS SECTION




EG&G PRESSURE SCIENCE



RIGID JOINTS

EG&G PRESSURE SCIENCE

- Life-of-the-Aircraft
- Best for ducts needing frequent access.
- High reliability.
- Robust design for ease of maintenance.



Psi Coupling


Male Flange

U-Plex® Seal

Female Flange

U-PLEX RIGID JOINT

EG&G PRESSURE SCIENCE



LEAKAGE CONTROL BETTER THAN .01 SCFM
PER INCH OF DUCT DIAMETER AT OPERATING CONDITIONS


JOINT DEFLECTIONS

EG&G PRESSURE SCIENCE

The Flanges "Rock," As
Shown, With Each
Pressure and Bending
Cycle

The Load on the Coupling
Shifts From (A) to (B)
Causing a Much Increased
Bending Moment on the
Coupling Channel

MAX STRESS




THE SEAL "OPENS" AND "CLOSES" WITH EACH CYCLE

**A Single Pressure Science Joint Was Qualified Through 1,100,000
Pressure Impulse Cycles Combined With 221,000 Bending
Moment Cycles, Equivalent to 100,000 Flight Hours.**

U-PLEX RIGID JOINT

EG&G PRESSURE SCIENCE

- *Improves the Integrity and Robustness of Rigid Ducting Joints.*




- *Used on Turbine Engine Bleed Systems, Ecs, Anti-Ice, Etc.*

INCREASED ELASTIC DEFLECTION

EG&G PRESSURE SCIENCE

ADDITIONAL
SPRINGBACK
(2X)



AS1895 CAVITY
HEIGHT

INCREASED ELASTIC DEFLECTION

FLUID PRESSURE SCIENCE

■ BENEFITS

- Will Seal Weld Distorted Flanges**
(as much as 2.5 to 5 times the deformation accommodated by the standard E-seal)
- Less Rework of Ducting Joints**
- Relaxed Flange Flatness**
- Requirements**
- Reduced Manufacturing and Operating Cost for User**

FLANGE FLATNESS REQUIREMENTS

EG&G PRESSURE SCIENCE

STANDARD E-SEAL

U-PLEX SEAL

1.50 to 4.50 inch Duct
OD \Rightarrow .005" TIR

1.50 to 3.50 inch Duct
OD Low Profile \Rightarrow
.013" (*) Standard
Profile \Rightarrow .015" (*)

5.00 to 7.00 inch Duct
OD \Rightarrow .007" TIR

7.50 inch Duct OD
 \Rightarrow .008" TIR

3.50 to 7.50 inch Duct
OD Low Profile \Rightarrow
.026" (*) Standard
Profile \Rightarrow .020"

U-PLEX FEATURES

EG&G PRESSURE SCIENCE

■ **FEATURE**

- **Conforms to Local Deformation**
 - 1.50 to 3.50 DUCT OD \Rightarrow .011" per linear circumference
 - >3.50 to 7.50 DUCT OD \Rightarrow .018" per linear circumference


■ **BENEFIT**

- **Reduces Rework/Replacement Cost of Improperly Welded Flanges**

MAXIMUM STRESS

EG&G PRESSURE SCIENCE


@ 10% SECTION SATURATION vs. DEFLECTION



FLAT CAVITY LEAKAGE

EG&G PRESSURE SCIENCE

7.749 inch dia.



U-PLEX FEATURES

EG&G PRESSURE SCIENCE

■ **FEATURE**

- **Lower Force to Compress**
 - **E-SEAL \approx 60 lbs./circumferential inch**
 - **U-PLEX \approx 20 lbs./circumferential inch**

■ **BENEFIT**

- **Leakage Rate Comparable to That of an E-Seal, Less Wear of the Flange Sealing Faces.**

SAE AS1895 ENDURANCE TEST


EG&G PRESSURE SCIENCE

- **0 psi - 250 psi PRESSURE CYCLE**
- **0 in/lb - 6344 in/lb FLEXTURE CYCLE**
- **1200°F TEST TEMPERATURE**
- **200,000 CYCLE TEST**
- **LEAKAGE TEST EVERY 20,000 CYCLES**

AS1895 ENDURANCE TEST

EG&G PRESSURE SCIENCE

7.5 inch STD.PROFILE DUCT




AS1985 SAFETY LATCH TEST

EG&G PRESSURE SCIENCE

- *Simulated Catastrophic Bolt Failure*
- *Test Must Be Run 10 Times*
- *Allowable Leakage*
= 6 SCFM Per INCH DUCT DIA
- *Maximum Actual Leakage*
= 5.08 SCFM Per INCH DUCT DIA

CUSTOM ENGINEERED SEALING RING SECTIONS

EG&G PRESSURE SCIENCE



BENEFITS APPLICABLE TO A TURBINE ENGINE

EG&G PRESSURE SCIENCE

- ***Increased Elastic Deflection /
Conformance to Local Deformation***
- ***Improved Pressure Energization***
- ***Lower Force to Compress / Less
Wear***
- ***Minimized Stress Relaxation***
- ***Greater Resistance to High Cycle
Fatigue***