


Ce7a Test Rig for High Frequency Modulator Experiments







Outline

- Ce7a test rig design concept
- Ce7a Data acquisition (DAQ) system
- Ce7a future upgrades
- Summary

Ce7a Test Rig (design concept):




Experiment Equations (flow calculations):



Cleveland, Ohio, City Water

Experiment Pre-test Conditions (tuning process):






Host Computer:

- Standard computer
- Host Computer
- Matlab and Simulink software
- Data Acquisition (DAQ) System Components:
- dSPACE computer system
- dSPACE (ControlDesk) software
- PFI (Precision Filter, Inc) 28000 system
- PFI filter software

dSPACE System:

- Real-time operating system
- 32 Analog input channels (16 bit resolution)
- 6 Analog output channels (14 bit resolution)
- Programmable input and output voltage ranges (± 5 and 0-10 volts)
- Digitize analog high frequency response pressure and flow signals
- Perform control feedback processes (in real-time)



Experiment Model:

- Simulink model
- 5 KHz sample rate
- Modular layout

Rig transducers: P0, P2, P3, P4
DP32, DP43, Flow Devices, etc...

Analog
Inputs
Signals

Experiment
device
transducers:
temperature,
distance,
etc...

Flow
Computation
Block


Analog
Control
Outputs
Signals

- ControlDesk software
- Data display(s)
- Data saving (50 Hz and 5K Hz)
- Real-time interaction with hardware
- Sample Rate 5 KHz




PFI 28000 System:

- Programmable analog channels (16 signal conditioners, 16 amplifiers)
- High performance filter(s): Butterworth, Bessel, High, Low, and Band pass filters
- Up to 200 kHz “filtered” bandwidth
- Graphical User Interface (GUI)



DAQ System Component Flow Diagram:





Test Rig


Instrumentation
Rack

Support
Electronics

Ce7a Facility Upgrades:

- Rebuild Ce7a test rig experiment process

- PLC
- Electric
- Control





- Ce7a test rig design concept:
 - To simulate a fuel delivery circuit for an aircraft combustion system
 - To assess the performance of a high frequency modulator device
- Data acquisition system capabilities:
 - Configured to condition high frequency response transducer for pressure and flow measurements
 - Perform real-time data acquisition processes (display and record experiment data)
 - Customize experiment processes for a modulator device
- Ce7a future upgrades:
 - Automate the experiment set up process
 - Reduce experiment set up time
 - Increase data reliability and repeatability
 - Rebuild test rig to expand its working space



QUESTIONS?